



## Bluepath Setup Guides


### Configuring the NetGenie – Ethernet with static IP addressing

This process is for setting the NetGenie up with an Ethernet connection and is essentially a manual setup. You will be skipping the NetGenie Network Configuration Wizard. You will need to configure the NetGenie through a web browser.




The first task is to set the NetGenie's own IP address.

To do this first setup a MS Windows device (PC/Laptop) with an RJ45 Ethernet connection directly to Eth Port 1 on the NetGenie. You should not need to change the standard IP addressing for the Ethernet adapter of your device.




IF you do need to change it, it can be done through the Network and sharing Centre in Windows.



Once confirmed and saved, power up the NetGenie and skip the Network Configuration Wizard. This will bring you to the Network Settings Menu and the overview tab. Select the Internet Tab in the sidebar.

Select and create the Ethernet connection choosing the static connection.


## Bluepath Setup Guides



Here enter the Static IP address that has been supplied by your ISP. The Subnet should be entered as 255.255.255.0.

Enter the Gateway IP address and the Primary DNS Server. Then Apply.

You can now go to the Local Network tab under the Network Settings Menu and set the local network IP address range and enable DHCP if desired



Once complete you will need to restart your systems and devices making sure that they accept the new DHCP IP addressing.

If you have any difficulty either contact;  
Bluepath at [netgenie.support@bluepath.co.uk](mailto:netgenie.support@bluepath.co.uk) or  
NetGenie Support, [support@netgenie.net](mailto:support@netgenie.net).